



solid metal
golf sprinkler nozzles

T655S-WP NOZZLE SET

for **Toro® 655S Series** (T655S) - White & Pink Spreaders

Spreader Nozzle Set

Installation Instructions

Step 1 REMOVE FACTORY NOZZLES

Remove old plastic *SPREADER* nozzles from nozzle base.

Step 2 INSTALL NEW SPREADER NOZZLES

Using a $1^{3}/_{32}$ " hex socket, install the *CLOSE-IN / MID-RANGE* FCI Nozzles on either side of range nozzle.



Step 3 RE-INSTALL NOZZLE BASE

in conversion assembly with cap.

www.underhill.us
1-866-UNDERHILL